
# **YUNFA**

# Untethered Furniture Adapter



Connects Untethered Battery (YUNBA) with Untethered furniture (Untethered Expansion Flip-Top Table (YUNFT), Untethered Navigate Base Only (YUNAH ) and Untethered Media Rover (YUNMS).

# What's Included

One Untethered Battery Furniture Adapter with specified mounting hardware.

#### Notes

One unit houses one Untethered Battery (YUNBA).

Untethered Battery (YUNBA) and Untethered Furniture are required and specified separately.

Untethered Furniture Adapter mounts to Untethered Furniture (Untethered Expansion Flip-Top Table (YUNFT), Untethered Navigate Base Only (YUNAH) and Untethered Media Rover (YUNMS) only.

For indoor use only.

Maximum output of 120 W. Do not exceed 120 W in total electrical consumption. Unterhered Furniture Adapter will automatically shut off when maximum output is exceeded as a safety feature. Consult User Guide for troubleshooting instructions.

Battery charge will gradually deplete over time when left installed on Untethered Furniture Adapter.

### PRODUCT OPTIONS

Configuration	Cradle Type	Metal Paint Finish
01 Counterbalance Table	<b>D0250</b> 250 Watt-Hours	Foundation
02 Rectangular Flip-Top Table		Mica
03 Mobile Media Rover		Accent

## SAMPLE ORDER CODE

YUNFA 01	D0250	60
----------	-------	----

DESCRIPTION	
-------------	--

Counterbalance Table (01)	
Rectangular Flip-Top Table (02)	
Mobile Media Rover (03)	

PRICING

1 1(1)	NG .
200	
194	
179	