## storage electrics

E W D B 4-Way Splitter	The Four-Way Splitter attaches to a harness to split power at floor level.  WHAT'S INCLUDED  1 four-way splitter and hardware.
E W I C I-Connector	The I-Connector is used to join two harnesses when a single harness length is not long enough.  WHAT'S INCLUDED  1 I-connector.
PRODUCT OPTIONS  Country of Installation	
A Canada/U.S.A.	
SAMPLE ORDER CODE EWIC A	

EWIC I-CONNECTOR

53

EWDB FOUR-WAY SPLITTER

171