
## J N D B C S Structural Beam Cover – Side



This cover finishes the side of the structural beam.

### WHAT'S INCLUDED

 $1\ \mbox{side-mounted}$  beam cover (with or without power and data, as specified) and mounting clips.

#### WHAT'S EXCLUDED

Structural Beam, Chicago Structural Beam, voice and data faceplate.

#### NOTES

The Opening Position option (B) is **not** available on 24" to 48" wide covers.

The Opening Position option (L or R) is not available on 24" to 42" wide covers.

The Opening Position option (C) is  ${\bf not}$  available on 24", 48", 54" and 60" wide

Opening Position option  $\boldsymbol{cannot}$  be specified with No Opening (N) Power and Data Opening.

When Post - 120° (Y) Width Reduction - Left Side is specified, the Post - 120° (Y) Width Reduction - Right Side is not available.

When Data Opening is specified, a Communication Extender Plate must be used to install voice and data faceplate.

### PRODUCT OPTIONS

Power and Data Opening	Width	Width Reduction – Left Side	Width Reduction – Right Side	Opening Position (If Applicable)	Finish
<b>D</b> Power and Data	24, 30, 36, 42, 48, 54,	A Beam – Half	A Beam – Half	B Both Ends	Foundation
P Power Only	60, 66, 72, 78, 84	B Beam – Full	<b>B</b> Beam – Full	C Center	Mica
N No Opening		R Support – Half	R Support – Half	L Left	Accent
		S Support – Full	S Support – Full	R Right	
		Y Post – 120°	Y Post – 120°		
		N None	N None		

#### SAMPLE ORDER CODE

# DIMENSIONS INCHES / MM

W	
24 / 610	
30 / 762	
36 / 914	
42 / 1067	
48 / 1219	
54 / 1372	
60 / 1524	
66 / 1524	
72 / 1829	

78 / 1981 84 / 2134

### **PRICING**

NO OPENING (N)	
59	
63	
69	
73	
80	
83	
87	
90	
96	
99	
103	

POWER AND DATA (D) OR POWER ONLY
n/a
82
85
89
94
98
101
110
113
117
122