JNWBB

Beam-Mounted Worksurface **Brackets**



Brackets are used to attach a worksurface on a structural beam. This item must be specified only as a replacement part or when the structural beams are not specified with worksurface brackets.

WHAT'S INCLUDED

2 worksurface brackets and attachement hardware.

NOTES

Finished in Black.

6.6.6.6.6.6.6.6.6.6.6.6.6.6.6.6.6.6.6.
Double-Sided (D)

PRODUCT OPTIONS

Worksurface Configuration								
D 1	Double-Sided							
S S	Double-Sided Single-Sided							

SAMPLE ORDER CODE

JNWBB S

JNWFP Linking Plates

The Linking Plates are used to maintain alignment of worksurfaces.

WHAT'S INCLUDED

2 linking plates and attachement hardware.

NOTES

Finished in Black.



JNWBB BEAM-MOUNTED WORKSURFACE BRACKETS

Price	
21	

JNWFP LINKING PLATES

Price			
20			