**K**
**Locks and Keys**

**WHAT'S INCLUDED**
**Style M:** 1 Master Key.

**Style R:** 1 Lock Removal Key.

**Style C:** 1 Lock Core and Keys.

**NOTES**
The Master Key unlocks any storage unit.

The Lock Removal Key removes lock cores from storage units.

Lock Cores and Keys are replacements for those currently installed.



Master
Key

Lock
Removal Key

Lock Core
and Keys

**PRODUCT OPTIONS**

| Style |
| --- |
| **M**  Master Key |
| **R**  Lock Removal Key |
| **C**  Lock Core and Keys |

**SAMPLE ORDER CODE**

| **K C** |
| --- |

| STYLE | PRICING |
| --- | --- |
| M | 7 |
| R | 7 |
| C | 30 |