

The Stage to Worksurface Support is used to attach worksurfaces to the Stage.

WHAT’S INCLUDED


2 brackets and attachment hardware.

NOTES

Height-Adjustability range is +3"/-3".

HTWQ

Stage to Worksurface Support



PRODUCT OPTIONS

Style	Finish
F Fixed	Foundation
H Height-Adjustable	Mica
	Accent

SAMPLE ORDER CODE

HTWQ H	74
--------	----

PRICING

FIXED (F)		HEIGHT-ADJUSTABLE (H)	
Foundation	Accent/Mica	Foundation	Accent/Mica
284	298	330	350