

HTWY
Worksurface Support Wire Manager

The Worksurface Support Wire Manager is an add on to the worksurface support that provides additional wire management from the worksurface and the stage.

WHAT’S INCLUDED
1 wire management support.

NOTES
Wire Manager is designed to use the same connection fasteners that accompany the Stage to Worksurface support (HTWQ).



PRODUCT OPTIONS

Support Style	Finish
Q Stage to Worksurface Support	Foundation Mica Accent

SAMPLE ORDER CODE

HTWY Q	74
--------	----

PRICING

STAGE TO WORKSURFACE SUPPORT (Q)

Foundation	Accent/Mica
44	53