

The Split Base Feed is hard-wired to the building power supply in two places. It is installed in the base opening of the panel and feeds power up into the panel raceway.

**WHAT'S INCLUDED**


1 split base feed, 1 electrical conduit support plate, 1 wiring junction box, hardware.

**NOTES**

Approved for use in NY York City.

Cannot install on panel with baseboard element.

**B F K S**  
**Split Base Feed**



**PRODUCT OPTIONS**

Wire System	Length	Country of Installation
4B 4-Wire	72	A Canada/U.S.A.
5D 5-Wire		
7G 7-Wire Isolated Ground		
8T 8-Wire Isolated Ground		
8N 8-Wire Separate Neutral		
8K 8-Wire Dual Isolated		

**SAMPLE ORDER CODE**

<b>BFKS 5D</b>	<b>72</b>	<b>A</b>
----------------	-----------	----------

**WIRE SYSTEM**

**PRICING**

4B	348
5D	401
7G	428
8T	445
8N	514
8K	567