


**Xpress**

## THCWQ

### Casual Linking Device



The Casual Linking Device is used to connect temporarily two freestanding tables together. It can be linked in lateral or back-to-back position depending of the type of the worksurface specified.

#### WHAT'S INCLUDED

2 casual linking devices and mounting hardware.

#### NOTES

Cannot be specified on desks and Hub Tables.

Can be used with Casual Modesty Panel only, but the Connecting Trapeze Modesty Panels can also be used with Casual Linking Devices.

Finished in Black.

---

#### PRICING

---

31

---

216

---

**Xpress**

## THCWF

### Fixed Linking Plates



These plates are used to attach firmly two freestanding tables together.

#### WHAT'S INCLUDED

2 linking plates and mounting hardware.

#### NOTES

Cannot be specified on Rectangular Flip-Top Tables.

Finished in Black.

---

#### PRICING

---

25

---