## TXP Porky<sup>®</sup>



## What's Included

1 Porky CPU trolley, 1 wire manager, 4 casters (2 front lockable) and assembly hardware.

## Notes

Width of the trolley can be adjusted from 3" to 10" to accommodate a wide range of computer CPUs. Please check the width of your CPU before ordering.

Expandable bottom provides appropriate ventilation for most CPUs. However, if vents are located on the sides of the CPU, 1" should be allowed on either side for sufficient air flow.

Casters are finished in Black.



## PRODUCT OPTIONS

Finish Option

210

E	Black
J	Granite
Q	Storm White
SA	AMPLE ORDER CODE
T	XP E
ΡI	RICING
_	

288