


The Four-Way Splitter attaches to a harness to split power at floor level.

WHAT'S INCLUDED

1 four-way splitter and hardware.

**EWDB
4-Way Splitter**



The I-Connector is used to join two harnesses when a single harness length is not long enough.

WHAT'S INCLUDED

1 I-connector.

**EWIC
I-Connector**



PRODUCT OPTIONS

Country of Installation

A Canada/U.S.A.

SAMPLE ORDER CODE

EWIC A

**EWDB
FOUR-WAY SPLITTER**

124

**EWIC
I-CONNECTOR**

38