


## EWDB 4-Way Splitter

The Four-Way Splitter attaches to a harness to split power at floor level.

### WHAT'S INCLUDED

1 four-way splitter and hardware.



## EWIC I-Connector

The I-Connector is used to join two harnesses when a single harness length is not long enough.

### WHAT'S INCLUDED

1 I-connector.



### PRODUCT OPTIONS

Country of Installation
-------------------------

A Canada/U.S.A.
-----------------

### SAMPLE ORDER CODE

EWIC A
--------

EWDB FOUR-WAY SPLITTER
---------------------------

142
-----

EWIC I-CONNECTOR
---------------------

44
----