


## EWDB

### 4-Way Splitter

The Four-Way Splitter attaches to a harness to split power at floor level.

#### WHAT'S INCLUDED

1 four-way splitter and hardware.



## EWIC

### I-Connector

The I-Connector is used to join two harnesses when a single harness length is not long enough.

#### WHAT'S INCLUDED

1 I-connector.



#### PRODUCT OPTIONS

##### Country of Installation

A Canada/U.S.A.

#### SAMPLE ORDER CODE

EWIC A

EWDB  
FOUR-WAY SPLITTER

165

EWIC  
I-CONNECTOR

51