E W D B 4-Way Splitter	The Four-Way Splitter attaches to a harness to split power at floor level. WHAT'S INCLUDED 1 four-way splitter and hardware.
E W I C I-Connector	The I-Connector is used to join two harnesses when a single harness length is not long enough. WHAT'S INCLUDED 1 I-connector.
PRODUCT OPTIONS	
A Canada/U.S.A.	
SAMPLE ORDER CODE	

EWIC I-CONNECTOR

53

EWIC A

171

EWDB FOUR-WAY SPLITTER