

The Power In feed cable brings power from the building to the panel. It can be installed in the base opening of the panel to feed power up to the CALA power module. It can also be brought down from the ceiling to the workstation.


**V B P D**  
**CALA Power In Feed**

**WHAT'S INCLUDED**

1 input power cable, 1800mm in length

**NOTES**

Country of Installation is required to determine correct source plug in option is chosen.



**PRODUCT OPTIONS**

Length	Country of Installation
18 1800 mm	R Argentina N Brazil L Chile

**SAMPLE ORDER CODE**

V B P D	18
---------	----

**PRICING**

281
-----