

**JNESBF****Split Base Feed**

The Split Base Feed connects to the building supply and routes power into the workstation from the wall or floor.

WHAT'S INCLUDED

1 split base feed and mounting hardware.

WHAT'S EXCLUDED

i-Connector and Four-Way Splitter.


NOTES

The Split Base Feed is mounted under a Structural Beam (JNDBB), EZ Fence Beam (JZSBB), EZ Fence Beam for Corridor (JZSBS), Chicago Structural Beam (JNDCB), Chicago EZ Fence Beam (JZSCB) or Chicago EZ Fence Beam for Corridor (JZSCS).

The connection to the building power supply and in the junction box must be executed by a qualified electrician.

Check local codes for limits or restrictions on harness length.

Refer to Application Guide for applications.

**PRODUCT OPTIONS**

Mounting Style	Wire System	Length	Country of Installation	PVC Option
B Beam-Mounted	7K 7-Wire Dual Non Isolated	036, 072	A Canada/U.S.A.	S Standard
	7T 7-Wire Non Isolated Ground			V PVC Free
	8K 8-Wire Dual Isolated			
	8T 8-Wire Isolated Ground			

SAMPLE ORDER CODE

JNESBF B	8T	072	A	S
-----------------	-----------	------------	----------	----------

**DIMENSIONS
INCHES / MM**

L
36 / 914
72 / 1829

PRICING

STANDARD (S)	PVC FREE (V)
7T, 8T, 7K or 8K	7T, 8T, 7K or 8K
348	377
376	454