

J N W B B

Beam-Mounted Worksurface  
Brackets



Single-Sided (S)



Double-Sided (D)

PRODUCT OPTIONS

Worksurface Configuration
D Double-Sided
S Single-Sided

SAMPLE ORDER CODE

JNWBB S

Brackets are used to attach a worksurface on a structural beam. This item must be specified only as a replacement part or when the structural beams are not specified with worksurface brackets.

**WHAT'S INCLUDED**  
2 worksurface brackets and attachment hardware.

**NOTES**  
Finished in Black.

J N W F P

Linking Plates



The Linking Plates are used to maintain alignment of worksurfaces.

**WHAT'S INCLUDED**  
2 linking plates and attachment hardware.

**NOTES**  
Finished in Black.

JNWBB BEAM-MOUNTED WORKSURFACE BRACKETS
Price
21

JNWFP LINKING PLATES
Price
20