

## J N W B B

### Beam-Mounted Worksurface Brackets


Brackets are used to attach a worksurface on a structural beam. This item must be specified only as a replacement part or when the structural beams are not specified with worksurface brackets.

**WHAT'S INCLUDED**

2 worksurface brackets and attachment hardware.

**NOTES**

Finished in Black.



Single-Sided (S)



Double-Sided (D)

**PRODUCT OPTIONS**

Worksurface Configuration

D Double-Sided

S Single-Sided

498

**SAMPLE ORDER CODE**

JNWBB S

## J N W F P

### Linking Plates


The Linking Plates are used to maintain alignment of worksurfaces.

**WHAT'S INCLUDED**

2 linking plates and attachment hardware.

**NOTES**

Finished in Black.



**JNWBB  
BEAM-MOUNTED WORKSURFACE BRACKETS**

Price

14

**JNWFP  
LINKING PLATES**

Price

13

