

J N W B B

Beam-Mounted Worksurface Brackets


Brackets are used to attach a worksurface on a structural beam. This item must be specified only as a replacement part or when the structural beams are not specified with worksurface brackets.

WHAT'S INCLUDED

2 worksurface brackets and attachment hardware.

NOTES

Finished in Black.



Single-Sided (S)



Double-Sided (D)

PRODUCT OPTIONS

Worksurface Configuration

D Double-Sided

S Single-Sided

SAMPLE ORDER CODE

JNWBB S

J N W F P

Linking Plates


The Linking Plates are used to maintain alignment of worksurfaces.

WHAT'S INCLUDED

2 linking plates and attachment hardware.

NOTES

Finished in Black.



**JNWBB
BEAM-MOUNTED WORKSURFACE BRACKETS**

Price

14

**JNWFP
LINKING PLATES**

Price

13