

The Power Pole Divider separates power cables from communication cables inside a Column-Mounted Power Pole.

**WHAT'S INCLUDED**

1 power pole divider.

**WHAT'S EXCLUDED**

Column-Mounted Power Pole.


**NOTES**

The Power Pole Divider extends beyond the length of a Column-Mounted Power Pole to separate power and communication cables below the worksurface.

Cannot be used in a lateral Power Pole.

**RLSD**

**Power Pole Divider**



**PRODUCT OPTIONS**

Length
96

**SAMPLE ORDER CODE**

**RLSD 96**

DIMENSIONS INCHES / MM	PRICING
L	
96 / 2438	55