Xpress

RLUDB

The Communication Box can be screwed under the worksurface at the desired location.

## WHAT'S INCLUDED

1 communication box

# Communication Box

### WHAT'S EXCLUDED

Voice/data faceplates and jacks (must be field supplied and installed) and Wire Management Clips.

#### NOTES

The communication box has an opening of 2.71" x 1.38" (69 mm x 35 mm).

Finished in a Platinum Coordinate.



#### **PRICING**

39