

The Communication Box can be screwed under the worksurface at the desired location.

**WHAT'S INCLUDED**

1 communication box

**WHAT'S EXCLUDED**


Voice/data faceplates and jacks (must be field supplied and installed) and Wire Management Clips.

**NOTES**

The communication box has an opening of 2.71" x 1.38" (69 mm x 35 mm).

Finished in a Platinum Coordinate.

**RLUDB**  
**Communication Box**



**PRICING**

38