



# XPEPBF Base Feed

The Base Feed connects to the building supply and routes power into the workstation from the wall or floor.

**WHAT'S INCLUDED**

1 base feed harness and hardware.

**WHAT'S EXCLUDED**

Power Harness Extension, Power Box, Power Box for Electrical Tray, Wire Management Cover and Base Feed Power Pole.


**NOTES**

Must be used with Wire Management Covers (XPWLA, XPWLS or XPWPA).

The connection to the building power supply must be executed by a qualified electrician.

The same wire system must be specified for all electrical components in a configuration.

Check local codes for limits or restrictions on harness length.



**PRODUCT OPTIONS**

Wire System	Length (Inches)	Country of Installation
<b>4B</b> 4-Wire	036, 042, 048, 054, 060, 066, 072, 078, 084	<b>A</b> Canada / U.S.A.
<b>7T</b> 7-Wire Non Isolated Ground		
<b>7K</b> 7-Wire Dual Non Isolated		
<b>8T</b> 8-Wire Isolated Ground		
<b>8K</b> 8-Wire Dual Isolated		

**SAMPLE ORDER CODE**

<b>XPEPBF 7K</b>	<b>072</b>	<b>A</b>
------------------	------------	----------

**DIMENSIONS  
INCHES / MM**

L
36 / 914
42 / 1067
48 / 1219
54 / 1372
60 / 1524
66 / 1676
72 / 1829
78 / 1981
84 / 2134

**PRICING**

4-Wire (4B)	7- or 8-Wire (7T, 7K, 8T or 8K)
295	340
296	343
298	346
299	349
303	351
306	355
307	361
311	364
312	368