The Navigate Split Base Feed delivers power from the floor to the Power Module. It is wired to the building power supply in two places for New York City wiring restrictions.

## WHAT'S INCLUDED

I base feed harness, junction box, I-connector, mounting hardware, additional cover is included when End Condition (E) is specified.

## NOTES

In the End Condition (E), the Split Base Feed can connect directly to the Power Module when the I-connector is removed. An additional Power Harness is not required to make this connection.

In the Mid Condition (M), the Split Base Feed module mounts directly to the Frame Link using an additional bracket (included). A 48" Power Harness is required to connect to the Power Module in the Wire Channel.

## **PRODUCT OPTIONS**

	Wire System	Length		Style	PVC Option	0	Country of Installation
8T	8-Wire Isolated Ground	018, 072	E	End Condition	Standard	A	Canada/USA
8K	8-Wire Dual Isolated		M	Mid Condition	V PVC Free		
7T	7-Wire Non Isolated Ground						
7K	7-Wire Dual Non Isolated						

## SAMPLE ORDER CODE

HNBEBFS 8K072EVA
------------------

MENSIONS CHES / MM	PRICING						
	ISOLATED GROUNI	) (8T)	DUAL ISOLATED (8K)				
	End Condition	Mid Condition	End Condition	Mid Condition			
L	Standard PVC Free	Standard PVC Free	Standard PVC Free	Standard PVC Free			
18 / 457	397 436	457 497	504 555	564 615			
72 / 1829	472 520	529 564	580 639	639 699			
	NON ISOLATED GROUND (7T)		DUAL NON ISOLATED (7K)				
	End Condition Mid Con		End Condition	Mid Condition			
	Standard PVC Free	Standard PVC Free	Standard PVC Free	Standard PVC Free			
18 / 457	397 436	457 497	504 555	564 615			
72 / 1829	472 520	529 564	580 639	639 699			
· · · · · · · · · · · · · · · · · · ·		-					



HNBEBFS

Navigate Split Base Feed