The Base Feed is used to route power from the floor to the Power Module.

### WHAT'S INCLUDED

1 base feed with bracket (s), i-connector, mounting hardware.

In the Mid Condition (M), the Base Feed mounts to the Frame Link using an additional bracket (included). A 48" Power Harness is required to connect to the Power Module in the Wire Channel.

# HNBEBF Navigate Base Feed



# PRODUCT OPTIONS

	Wire System	Length		Style	Cover Finish		PVC Option		Country of Installation
8T	8-Wire Isolated Ground	072, 144	E M	End Condition Mid Condition	Foundation Mica	Stan V	dard PVC Free	A	Canada/USA
8K	8-Wire Dual Isolated		141	Wild Condition	Accent	ľ	1 VOTICE		
7 <b>T</b>	7-Wire Non Isolated Ground								
7K	7-Wire Dual Non Isolated								

#### SAMPLE ORDER CODE

HNBEBF 8K	072	E	91	$\mathbf{v}$	A
-----------	-----	---	----	--------------	---

MID CONDITION

Standard PVC Free

#### **DIMENSIONS INCHES / MM**

## **PRICING**

72 / 1829	438	484	499	544	
144 / 3658	575	633	634	690	
	NON ISO	OLATED GRO	OUND (7T)		
	END CO	NDITION	MID CO	NDITION	
	Standard	PVC Free	Standard	PVC Free	
72 / 1829	438	484	499	544	
144 / 3658	575	633	634	690	

ISOLATED GROUND (8T) END CONDITION

Standard PVC Free

DUAL ISOLATED (8K)						
END CO	NDITION	MID CONDITION				
Standard	PVC Free	Standard	PVC Free			
551	606	610	665			
716	789	776	846			

DUAL NON ISOLATED (7K)						
END CO	NDITION	MID CONDITION				
Standard PVC Free		Standard	PVC Free			
551	606	610	665			
716	789	776	846			