

The Four-Way Connector connects to receptacle or pass-through harness to route power in three directions for distribution between two to four adjacent panels. Outlets cannot be connected to the Four-Way Connector.


WHAT'S INCLUDED

1 four-way connector.

E F

Four-Way Connector

317



PRODUCT OPTIONS

Wire System	Country of Installation
4B 4-Wire	A Canada/U.S.A.
5D 5-Wire	
7G 7-Wire Isolated Ground	
8T 8-Wire Isolated Ground	
8N 8-Wire Separate Neutral	
8K 8-Wire Dual Isolated	

SAMPLE ORDER CODE

EF 5D	A
--------------	----------

WIRE SYSTEM	PRICING
4B	97
5D	97
7G	131
8T	131
8N	148
8K	166