

Intermediate Panel Spacer

The Intermediate Panel Spacer creates and covers an intermediate-height space between two panels which are connected side-by-side at 180°.


WHAT'S INCLUDED

1 intermediate-height 180° outer cover, 1 intermediate-height 180° inner cover, 1 two-way 180° corner cap, two-way 180° corner braces, Posi-Lock and spring plate assemblies.

NOTES

Must be specified in conjunction with Intermediate Spacer Cover (TEI_08).

Cannot combine square and radius edge trims.



PRODUCT OPTIONS

Edge Style	Height	Configuration	Spacer Finish	Top Cap Finish (If Fabric spacer is selected)
R Radius (Foundation, Mica)	06, 09, 12, 15, 18, 21, 24, 30, 36, 39, 45, 51	00 Intermediate Panel Spacer	Foundation Mica Fabric	Foundation
S Square (Foundation, Mica)				Mica

SAMPLE ORDER CODE

TCI S	06	00	FX	E
--------------	-----------	-----------	-----------	----------

DIMENSIONS INCHES / MM

H
6 / 152
9 / 229
12 / 305
15 / 381
18 / 457
21 / 533
24 / 610
30 / 762
36 / 914
39 / 991
45 / 1143
51 / 1295

PRICING

RADIUS EDGE (R)

Foundation	Mica	Fabric				
		A/COM	Gr. 1	Gr. 2	Gr. 3	Gr. 4
26	26	30	32	35	38	40
46	46	54	58	61	64	66
47	47	56	59	62	65	68
47	47	59	62	65	68	71
54	54	61	64	66	70	72
56	56	62	65	68	71	74
56	56	70	72	75	78	82
75	75	81	87	91	94	98
78	78	87	91	94	97	100
79	79	92	95	98	100	104
85	85	97	99	102	107	111
89	89	100	106	110	112	115

SQUARE EDGE (S)

Foundation	Mica	Fabric				
		A/COM	Gr. 1	Gr. 2	Gr. 3	Gr. 4
46	59	59	65	71	76	81
97	107	107	112	118	126	131
99	110	110	114	120	129	134
99	114	114	120	129	136	139
107	118	118	126	134	138	141
110	120	120	129	136	140	143
110	138	138	142	148	162	168
148	168	168	173	177	184	187
162	173	173	177	184	193	199
165	180	180	189	196	202	207
170	193	193	199	207	211	214
175	202	202	209	215	224	227