

The Perforated Element allows passive air circulation between adjacent work areas.

**WHAT'S INCLUDED**


1 element, installation hardware.

**NOTES**

Cannot use Perforated Element at level 2 of raceway panel.

Cannot be used with on-module worksurface supports.

**THF  
Perforated Element**



**PRODUCT OPTIONS**

Height	Width	Finish
15	18, 24, 30, 36, 42, 48, 54, 60	Foundation Mica

**SAMPLE ORDER CODE**

<b>THF 15</b>	<b>24</b>	<b>D</b>
---------------	-----------	----------

**DIMENSIONS  
INCHES / MM**

H	W
15 / 381	18 / 457
15 / 381	24 / 610
15 / 381	30 / 762
15 / 381	36 / 914
15 / 381	42 / 1067
15 / 381	48 / 1219
15 / 381	54 / 1372
15 / 381	60 / 1524

**PRICING**

Foundation	Mica
147	184
155	191
173	210
191	226
208	244
234	268
249	289
271	307