


The Hutch to Worksurface Support mounts to the underside of a worksurface and to the Hutch to provide support for the worksurface.

WHAT'S INCLUDED

Brackets, as specified and attachment hardware.

H T W F

Hutch to Worksurface Support



PRODUCT OPTIONS

| Support Style | Style of Hutch | Width of Hutch | Depth of Worksurface | Finish |
|---------------|------------------------------------|--------------------------------|----------------------|------------------------------|
| F Fixed | S Single D Shared Y Aperture | 30, 36, 42, 48, 54, 60, 66, 72 | 24, 30, 36, 42, 48 | Foundation Mica Accent |

SAMPLE ORDER CODE

| | | | | |
|--------|---|----|----|----|
| HTWF F | Y | 60 | 30 | 74 |
|--------|---|----|----|----|

PRICING

| |
|-----|
| 113 |
|-----|