

## HTWQ

### Stage to Worksurface Support


The Stage to Worksurface Support is used to attach worksurfaces to the Stage.

**WHAT'S INCLUDED**


2 brackets and attachment hardware.

**NOTES**

Height-Adjustability range is +3"/-3".



Fixed



Height-Adjustable

**PRODUCT OPTIONS**

Style	Finish
F Fixed	Foundation Mica Accent
H Height-Adjustable	

316

**SAMPLE ORDER CODE**

HTWQ H	74
--------	----

**PRICING**

FIXED (F)		HEIGHT-ADJUSTABLE (H)	
Foundation	Accent/Mica	Foundation	Accent/Mica
195	206	228	241