

The Stage to Worksurface Support is used to attach worksurfaces to the Stage.


**WHAT'S INCLUDED**

2 brackets and attachment hardware.

**NOTES**

Height-Adjustability range is +3"/-3".

**HTWQ**  
**Stage to Worksurface Support**



**PRODUCT OPTIONS**

Style	Finish
F Fixed	Foundation Mica Accent
H Height-Adjustable	

**SAMPLE ORDER CODE**

<b>HTWQ H</b>	<b>74</b>
---------------	-----------

**PRICING**

FIXED (F)		HEIGHT-ADJUSTABLE (H)	
Foundation	Accent/Mica	Foundation	Accent/Mica
268	281	311	330