


The Storage Back to Worksurface Support is used to attach worksurfaces to storage.

**WHAT'S INCLUDED**


2 brackets and attachment hardware.

**HTWS**

**Storage Back to Worksurface Support**



Two Height-Adjustable Brackets



Two Height-Adjustable Brackets, One Hook

**PRODUCT OPTIONS**

Style	Finish
<b>H</b> Two Height-Adjustable Brackets	Foundation Mica Accent
<b>B</b> Two Height-Adjustable Brackets, One Hook	

317

**SAMPLE ORDER CODE**

<b>HTWS H</b>	<b>74</b>
---------------	-----------

**PRICING**

71
----