

## HTWY

### Worksurface Support Wire Manager

The Worksurface Support Wire Manager is an add on to the worksurface support that provides additional wire management from the worksurface and the stage.

#### WHAT'S INCLUDED

1 wire management support.

#### NOTES

Wire Manager is designed to use the same connection fasteners that accompany the Stage to Worksurface support (HTWQ).



#### PRODUCT OPTIONS

Support Style	Finish
Q Stage to Worksurface Support	Foundation Mica Accent

324

#### SAMPLE ORDER CODE

HTWY Q	74
--------	----

#### PRICING

##### STAGE TO WORKSURFACE SUPPORT (Q)

Foundation	Accent/Mica
33	38