

worksurfaces & countertops

WORKSURFACE OVERVIEW 118

WORKSURFACES BASICS 119

PLANNING WITH PANEL-MOUNTED WORKSURFACES 122

PLANNING WITH BULLET WORKSURFACES 125

KEYBOARD SUPPORT SURFACES 126

D-STYLE WORKSURFACE BASICS 127

PLANNING WITH D-STYLE WORKSURFACES 128

PLANNING WITH SMALL FOOTPRINT WORKSURFACES 130

SUPPORTING D-STYLE WORKSURFACES 131

EDGE TRIM STYLE OVERVIEW 133

GRAIN DIRECTION/USER EDGE –
LAMINATE & FLINTWOOD WORKSURFACES 134


GRAIN DIRECTION/USER EDGE – SOURCE LAMINATE
WORKSURFACES 135

GRAIN DIRECTION/USER EDGE – D-STYLE WORKSURFACES . . 135


worksurface overview

Leverage offers a variety of panel-mounted and semi-suspended worksurfaces for 90° and 120° applications. They are offered in Standard, D-Style and D-Style with scallops.


- Worksurfaces may **not** span more than 60" without support
- Reinforcements Channels and Supports are ordered separately unless otherwise specified
- Grommets are available for routing power to below the worksurface



Standard Worksurface




D-Style Worksurface



D-Style Worksurface
with Scallops

- Standard worksurfaces have a slightly rounded corner profile and have scallops on the back edge of the worksurface to facilitate wire management. The number of scallops depend on the size and shape of the surface
- D-style worksurfaces have square and radius corners
- D-style surfaces are available in depths and widths to match District storage
- D-style worksurfaces with scallops have square corners and scallops on the back edge of the worksurface to facilitate wire management. The number of scallops depend on the size and shape of the surface
- D-style surfaces are available in depths and widths to match District storage

All panel mounted worksurfaces have a 3/8" gap between the back edge of the worksurface and the panel to facilitate wire management.




Finishes

- Worksurfaces are available in Foundation Laminate and Flintwood
- Edge trim styles include Flat, Flintwood Flat and Full Knife
- Flintwood edge trims will be finished to match the surface
- Supports, when included are available in Foundation, Mica and Accent colors


worksurface basics

The following outlines the worksurface options for Leverage Standard worksurfaces.




corner worksurfaces


- **Corner Worksurfaces** are available for 90° and 120° applications
- Available with and without keyboard trays, in standard and extended sizes
- Used primarily as a dedicated corner for computer monitors and keyboards




Radius Corner Worksurface (KWRR)




Radius Corner Worksurface with Return and Keyboard Support (KWRK)



Standard Corner Worksurface (KWPS)



Curved Corner Worksurface (KWSC)



Split Radius Corner Worksurface (KWXC)




Standard Pentagon Worksurface (KWPG)




Extended Pentagon Worksurface (KWPE)

straight worksurfaces

- **Straight Worksurfaces** include Rectangular and Transition Worksurfaces
- Panel-mounted and provide a primary or secondary surface
- Can be used on- or off-module when suspended from a panel




Rectangular Worksurface (KWS)



Concave Worksurface (KWCC)


worksurface basics (continued)

The following outlines the worksurface options for Leverage worksurfaces.



bullet worksurfaces


- **Bullet Worksurfaces** provide a large semi-supported meeting area for both single and shared workstation configurations
- Provide panel stability when used to replace return Panels
- Must be suspended from a panel, and may not be used as panel-mounted worksurfaces or combined with Leverage supports to create freestanding desks



Bullet Worksurface
(KWBT)

worksurface basics (continued)

The following outlines the worksurface options for Leverage worksurfaces.




Finishes

Edge trim styles include Flat Trim

countertops

- **Countertops** are rectangular and mount on top of a Panel to provide a transaction surface
- Can be used alone or together with other countertops
- Widths wider than 36" can span two panels
- Can only be mounted on module
- May be used to wrap a corner but the lengths need to be adjusted for this application
- Countertops **cannot** be mounted over wood top trims
- Countertops **cannot** be used with corridor width elements




Rectangular Countertop
(KWCS)

- **Source Laminate Worksurfaces cannot** be used in conjunction with standard panel-mounted or in freestanding applications
- All Keyboard Trays and Accessories may be used with 30" deep Source Laminate worksurfaces
- All 24" deep worksurfaces under 54" in width may be used with all Accessories and Keyboard Trays
- **Cannot** be used with Desktop Mounted Screens


planning with panel-mounted worksurfaces

The following rules apply when planning with panel-mounted worksurfaces.

on-module and off-module mounting





Panel-mounted worksurfaces can be used on- or off-module when suspended from a panel.



All panel-mounted worksurfaces greater than 60" in width require a minimum of two panels for support because additional supports will be required.


spanning two panels

In planning scenarios where a panel-mounted worksurface is required to span two panels, the recommended width of the panel is half the width of the worksurface.



120° planning

120° worksurfaces are offered in a wide range of shapes, sizes and finishes.




- 120° worksurfaces must be panel supported, on-module
- 120° planning utilizes existing worksurface supports. Refer to specific product page for support applicability


planning with panel-mounted worksurfaces (continued)

radius corner worksurfaces


Radius Corner Worksurfaces can be planned with Infinity Curved Desk Edge Screens (GXCL).




The Rectangle Perpendicular with Radius Corner Worksurface (D-Style) (KWSD) with two Round 3" Radius Left.




The Rectangle Perpendicular with Radius Corner Worksurface (D-Style) (KWSD) with two Round 3" Radius Right.



The Rectangle Perpendicular with Radius Corner Worksurface (D-Style) (KWSD) with four Round 3" Radius.



Planning with two Round 3" Radius Corner Worksurfaces.




Planning with four Round 3" Radius Corner Worksurfaces


planning with panel-mounted worksurfaces (continued)

Semi-supported worksurfaces are ideal for workstations where only an electrified panel spine is required, eliminating the need for return panels.

panel mounted worksurfaces



Two support options are available for panel supporting worksurfaces, the Monoleg option and the Flush End Gable option.




With Flush End Gable

- All Panel supporting worksurfaces with a Flush End Gable include a Full-Height Modesty Panel
- The Full-Height Modesty Panel provides visual privacy, wire management and structural stability
- The Full-Height Modesty Panel is mounted flush to the rear edge of the worksurface


planning with bullet worksurfaces

Bullet worksurfaces provide a large semi-supported meeting area for both single and shared workstation configurations as well as Panel stability when used to replace return Panels.


single workstation




shared workstation



Guesting stations can be used in single and shared applications.





Bullet worksurfaces must be mounted perpendicular to the panel spine.




Bullet worksurfaces cannot run parallel to a panel.

keyboard support surfaces

Leverage offers a comprehensive range of keyboard support worksurfaces.





Split Radius Corner Worksurface
(KWCX)



Radius Corner Worksurface with
Return and Keyboard Support
(KWRK)


keyboard height adjustment mechanism




- The keyboard height adjustment range is, 13" overall (6-1/2" above the worksurface and 6-1/2" below the worksurface)
- Height adjustment is activated by a release paddle located on the right underside of the support the tilt adjustment range is +15° to -15°
- It is adjusted with a tension knob located on the underside of the support

d-style worksurface basics


The D-Style collection of Leverage worksurfaces provide the opportunity for a more refined aesthetic. Worksurfaces have square edges, an option for scallops and shapes that address rectangular District-like planning styles.



Rectangular Worksurface (D-Style) Shown



Rectangle Perpendicular
with Radius Corners
Worksurface (D-Style)
(KWSD)



Rectangular Worksurface
(D-Style) (KWSQ)

Finishes

- Worksurfaces are available in Foundation Laminate and Flintwood
- Edge trim styles include Flat, Full Knife, Flintwood Flat and Flintwood Knife
- Flintwood edge trims will be finished to match the surface
- Grommets are finished in Storm White, Platinum and Very White




- Available in depths and widths to align with District or Leverage storage, and are rectangular or wedged shape to provide the ability to plan deep primary worksurfaces and shallow secondary surfaces
- Worksurface corners are square
- Available with or without scallops
- User edge can be flat or full knife and all other edges are square
- Shared worksurface shapes include Fan or Tapered and provide a collaborative workspace for shared workstations
- Guest worksurfaces are available for semi-suspended worksurface configurations

planning with d-style worksurfaces

The following should be considered when planning with D-Style Leverage worksurfaces.

gapping




- Leverage worksurfaces have a $\frac{3}{8}$ " gap at the back of all worksurfaces, to allow clearance for elements, electrical cut outs etc, therefore worksurface depths have nominal dimensions. Worksurface widths also have nominal dimensions and are available in 1" increments. The actual widths are $\frac{1}{8}$ " than nominal dimension
- It is **not** recommended that the worksurface be mounted against the panel without a gap because the front edge will **not** align with storage components. District storage is sized to match Leverage worksurface depths including the gap. (see storage section)



Continuous gapping **cannot** be achieved because worksurface widths are in 1" increments, and the gap at the back of the worksurface is $\frac{3}{8}$ ".


Combinations of three rectangular or three guest surfaces **cannot** be used together because the gapping will be incorrect.

- When guest worksurfaces are used a continuous gap along the back can be achieved because the worksurfaces are complete with the $\frac{3}{8}$ " gap
- They are intended to be run perpendicular to the panel





planning with d-style worksurface (continued)

grommets




- Grommets can be located at either side of a worksurface, or at the center back of a worksurface




- 30" wide to 48" wide surfaces will have the center back grommet centered, because the location will **not** interfere with supports
- The 54" to 96" surfaces will have the center back grommet off center, to allow for necessary supports

planning with small footprint worksurfaces

Leverage provides a limited collection of small footprint worksurfaces that optimize efficiency within small scale workstation layouts.




Rectangle Perpendicular
with Radius Corners
Worksurface (D-Style)
(KWSD)




Rectangular Worksurface
(D-Style) (KWSQ)

Worksurfaces are available in depths of 17" to allow for maximum planning capability in temporary or permanent address workstations.

rectangular worksurfaces



17" deep surfaces provide adequate chair space in 5' x 5' workstations




When worksurfaces are requires above a 16" deep low storage, the cabinet depths will align

supporting d-style worksurfaces

supporting guest worksurfaces

- Guest worksurfaces must be attached to the panel at one end
- The opposite end can be supported by:
 - Expansion Legs
 - 1 District Gables
 - Leverage Post Legs or Slim Legs
 - 2 Monolegs
 - 3 District Pedestals

Note: If District gables are being used, there will be a difference in depth. District gables are 23" deep (actual) and Leverage worksurfaces are 23-5/8" deep (actual).



supporting with d-style worksurfaces (continued)

supporting panel-mounted worksurfaces

When worksurfaces are mounted facing a panel, a number of support options are available:

No Storage or Return Panel



Return Panel



When a panel return is being used, corner brackets are used



When no storage or return panel is being used, a post leg and corner bracket, a flush end gable, or a cantilever can be used.

Storage

















- When District storage is being used beside a worksurface, a Worksurface to Tower Bracket Kit (UWBT) is used for attaching the storage
- Other supports for attaching the storage to the tower, with surface to the panel are still required (See Supports Section)

edge trim style overview

Trim style and desk finish applications are summarized in the chart below.


Shading indicates the user edge

	Foundation Laminate Surface	Flintwood Surface	Natural Veneer Surface	Non-User Edge	Style
Flat (8) All Edges 		n/a	n/a	Flat (8)	D
Flintwood Flat (9) All Edges 	n/a				D
Full Knife (H) User Edge 	n/a (For D style only)				D
Flat (8) All Edges 		n/a	n/a	Flat (8)	
Flintwood Flat (9) User Edge Only 	n/a		n/a	Finished in a coordinating Flintwood flat trim	
Flintwood Full Knife (H) All Edges 	n/a		n/a	Finished in a coordinating Flintwood flat trim	


grain direction/user edge – laminate & flintwood worksurfaces

The illustrations below show the grain direction of Flintwood worksurfaces. Alternative grain directions are available on selected worksurface shapes for Flintwood only. See next page.


- Grain direction is an important factor when planning workstation configurations, if a different grain direction is required, contact your Teknion Customer Service Representative
- The pattern/grain direction of Laminate worksurfaces varies depending on the type of worksurface specified
- Shading indicates user edge




Rectangular Worksurface
(KWS)




Concave Worksurface
(KWCC)




Standard Corner
Worksurfaces
(KWPS)




Curved Corner Worksurface
(KWSC)




Split Radius Corner
Worksurface
(KWCX)




Radius Corner Worksurface
with Return
(KWRR)



Radius Corner Worksurface
and Return
(KWRK)




Standard Pentagon
Worksurface Straight
(KWPG)




Extended Pentagon
Worksurface
(KWPE)



Rectangular Countertop
(KWCS)



Extended Corner with
Transition Return with
Flush End Gable (KSEF)



Bullet Worksurface
(KWBT)

grain direction /user edge – source laminate worksurfaces

The illustrations below show grain direction of Source Laminate worksurfaces.

- Grain direction is an important factor when planning workstation configurations, if a different grain direction is required, contact your Teknion Customer Service Representative
- The pattern/grain direction of Source Laminate worksurfaces varies depending on the type of worksurface specified
- Shading indicates user edge



Source Laminate
Rectangular Worksurface
(KUWS)

grain direction/user edge – d-style worksurfaces

The illustrations below show grain direction of d-style worksurfaces.

- Grain direction is an important factor when planning workstation configurations, if a different grain direction is required, contact your Teknion Customer Service Representative
- The pattern/grain direction of d-style worksurfaces varies depending on the type of worksurface specified
- Shading indicates user edge



Rectangle Perpendicular
with Radius Corners
Worksurface (D-Style)
(KWSD)



Rectangular Worksurface
(D-Style) (KWSQ)